

How to apply your transfer

- 1** Our transfers are highly-detailed and can be used on wood, painted furniture, glass, mirrors and many other smooth surfaces.
- 2** The desired surface needs to be clean and dry. If you freshly painted the surface, allow for at least 48 hours to a week for the paint to properly dry before applying the transfer.
- 3** The transfers are pressure sensitive. When removing the transfer from the packaging, handle it carefully.
- 4** Each transfer consists of 2 sheets. The matte release paper and the other printed adhesive transfer.
- 5** Cut out the elements you want to use before removing the matte release paper.
- 6** With the release paper still attached, experiment with where you want to place the transfer.
- 7** Gently pull the release paper 1 – 2 inches from the top edge of the transfer. If working with a large design, tape down the top release corners of the transfer to ensure that the rub-on stays exactly in place while doing the transfer. Then slowly and carefully remove the rest of the release paper and tape down the corners and edges every few inches of the transfer.
- 8** Working from the top to the bottom, rub off the design using the enclosed transfer tool to ensure transfer of any of the small details that might have been missed.
- 9** Once the entire design has been transferred, make any touch ups desired and gently smooth down any bubbles or design edges by rubbing gently with a soft cloth.
- 10** Should you want to remove transfer design, it can be done by gently scrapping it off with a smooth edged tool. It may also help to soften the adhesive by blow drying the area first.